

## User instructions ClimaRad S-Fan+

### Operation of the ClimaRad S-Fan+



 Please note! The air supply opening must always remain open and unimpeded!

### Operation ClimaRad S-Fan+

The ClimaRad S-Fan+ can be operated by using the control panel on the underside of the device.



Control panel

## Function keys

### AUTO



Automatic control. The room ventilation is controlled automatically by your ClimaRad S-Fan+, which ventilates on the basis of CO<sub>2</sub> and RH measurements.



#### Manual: manual ventilation using outside air:

You can set your desired ventilation speed with the + and - keys on the control panel. After a period of 8 hours, the ClimaRad S-Fan+ will switch back to the automatic setting. Use this function for example when you want to lower the temperature in your bedroom by a few degrees at night in the summer (summer night ventilation).



Pause/Off. Use this function if you (temporarily) do not want to ventilate. After a period of 4 hours, the ClimaRad S-Fan+ switches back to the automatic setting. When the button is pressed for 5 seconds, the unit switches off. In case of emergencies you can use this function to switch off the device.



Comfort mode. The ClimaRad S-Fan+ will pre-heat the external air to 12°C. After a period of 4 hours, the ClimaRad S-Fan+ will switch back to the automatic setting.



Heating. By switching this function on, the ClimaRad S-Fan+ will heat the room. After a period of 2 hours, the ClimaRad S-Fan+ will switch back to the automatic setting.

The duration can be selected with the + and - keys on the control panel .



Child lock. The child lock will be activated when you press and hold the three buttons on the panel for 4 seconds.

## Messages

## Switch off



Child lock. The child lock is switched on. Press and hold the three buttons for 4 seconds to switch it off.



Press 4 seconds simultaneously



Malfunction. A malfunction has occurred. Contact your technician or housing corporation.

filter vervuild

Dirty filter. Replace the air filter or contact your technician or housing corporation. After replacement, press and hold the + and - buttons for 6 seconds.



Press for 6 seconds



Pairing. The ClimaRad S-Fan+ can be linked to other ClimaRad products. Press the buttons briefly and simultaneously.



Press briefly and simultaneously